

Power Green Vision

V-LFP48100 48V100Ah

Vision Technology delivers safe lithium iron phosphate

battery solutions for Telecom application.

Overview

The V-LFP 48V100Ah back-up lithium iron phosphate battery system is developed for backup of Telecom equipment. Under normal condition, grid AC power supply to rectifier module and the Telecom loads and charge battery pack; When the AC power fail, rectifier module stop power supply, the battery serves for Telecom equipment, to ensure the Telecom equipment runs normally; when the AC power is switched on again, power rectifier module for Telecom equipment recover to while charge the battery pack.



Features

- ▶ RS485/RS232 communication output for monitoring
- > Built-in BMS with Charging current limitation
- Built-in automatic protection for over-charge, over-discharge and over-temperature conditions
- State of charge and state of health indication
- > Built-in battery control for efficient operation
- Internal cell balancing
- Compatible with standard Telecom rectifiers
- Maintenance free

Specifications	V-LFP48100		
Voltage	48 V		
Nominal Capacity (40°C , 0.5C)	100 Ah		
Weight (Approximate)	43.0±0.3Kg		
	Normal energy (40°C , 0.5C)	5120 Wh	
Energy	Volumetric energy density	153Wh/L	
	Gravimetric energy density	119Wh/kg	
Dimensions (W*D*H)	Width*Depth* Height	442mm*425mm*178mm	
Impedance	(Max, at 1000Hz.)	<30mΩ	
Standard Discharge	Max. constant current	100A	
25°C	Cut-off voltage	43.2V	
	Charge Voltage	56V	
Standard charge	Max. constant current 100A		
25 ℃	Recommended charging current and time	30A(0.3C) for 3.5 hours	
Round trip efficiency(%)	>98%		
Calendar life	25℃	>10 years	
Cycle life (0.2C, 25℃)	80% DOD 4000 cycles		
Recommend operating tompor	Charging: 0°C~60°C		
Recommend operating temper	Discharging: -20°C~60°C		
Recommend storage temperate	Recommended range: 0 $^\circ \! \mathbb{C}^{\hspace*{1em}\sim\hspace*{1em}} 55 ^\circ \! \mathbb{C}$		

www.vision-batt.com



Power Green Vision

BMS Parameters.

NO.	-	[vno	Function	Setting value	Remarks	
NO.	NO. Type		Function	V-LFP48100 48V100Ah	Remarks	
1	- Voltage	Charge	Cell Voltage Protection	3.90V Protection	Recover at 3.6V	
2			Total Voltage Protection	60.0V Protection	Recover at 54.0V	
3		Discharge	Cell Voltage Protection	2.5V Protection	Recover at 3.1V	
4			Total Voltage Protection	43.2V Protection	Recover at 48.0V	
5	Current	charge	Normal	≤100A		
6		Discharge	Normal	≤100A		
7			Over Current Protection 1	>100A and $<$ 150A	Delay 30s ,recovery in every 60s	
			Over Current Protection 2	>150A and $<$ 200A	Delay 3s ,recovery in every 60s	
8			Short Circuit Protection	≥200A	Delay 1mS	
9	Temp	Cell Temp 1	Low temp protection	Charging $<$ 0°C Discharging $<$ -20°C	Delay 1~2S	
10		Cell Temp 2	High temp protection	Charging $>$ 70°C Discharging $>$ 75°C	Delay 1~2S	
11		PCB	Range	≥95℃	Recovery at 75 $^\circ\!\mathrm{C}$	
12	Cell Balance	Balance	Make all cells be balance during charging process. Current: 150mA	$V_{Max} \ge 3.40V$ and $V_{Max} - V_{Min} \ge 40mV$, Start balance	All cell voltages ${\leqslant}3.65V$ and $V_{Max.}$ - $V_{Min} {\leqslant}40mV,$ Stop balance	

Battery Status.


- 1. Stop/Transport Mode. In working mode, turn off air switch, battery will go to STOP mode with low self-discharge. In STOP mode, charging MOS and discharging MOS are turn off, battery cannot charge, discharge or communicate.
- 2. Working Mode. In STOP mode, connect the battery to SMPS, turn on air switch, battery will go to working mode. In working mode, BMS will monitor battery voltage, current, and temp and communication is available, charging MOS and discharging MOS are closed, Battery will operate as the settings.
- 3. Sleep Mode. After turn on the battery, if the battery voltage below low voltage protection, BMS will go to sleep mode in 1 minute. In sleep mode, charging MOS and discharging MOS are closed; BMS will check the current in every 1 Min, if there is charging current connecting; battery will turn to working mode.
- 4. Error Mode. In working mode, if there is: ①.Battery cells, $\Delta U > 2.5V$, or ②.Any cell voltage >4.1V or <0.5V, or ③. Battery temp is <-30°C or +100°C. BMS will go to error mode, ALM will bright and other LED will shut down, and go to STOP mode, charging MOS and discharging MOS are turn off. Need to make troubleshoot.

www.vision-batt.com



Power Green Vision

Performance Curve.



Performance may vary depending on, but not limited to cell usage and application. If cell is used outside specifications, performance will diminish. All specifications are subject to change without notice. All information provided herein is believed, but not guaranteed, to be current and accurate.